FUSE 8P

 ∞ 30.0 Amps C0585-28 R,2.5D,5755

501-10 - SEATING --- JLR 21 16 10_3E - RANGE ROVER iEWD (RHD) (3a) 334434 > --- (1 / 2)Battery_ C1661-1 R,25.0F,375 C0045-1 B,35.0,430 12.0 Volts Junction box-Battery C0632-FL3B C3403-1 RY.6.0D.930 C2412-29 C2411-29 RY.6.0D.665 50.0 Amps Junction box-Central FUSE 40P C0582-6 RG,0.5D,1810 SI239 RG.0.5D.4390 C3040-8 C2946-8 RG,0.5D,280 0 5.0 Amps RG,0.5D,2735 C3041-8 C2947-8 RG,0.5D,240 Switchpack-Seats-Rear-Right C0436-19_C0510-19 B,0.5D,1855 C3522-1 C0510-11C0435-11 R,0.5D,8475 C3540-12C3541-12 R,0.5D,150 SJ742 R,0.5D,245 RG,0.5D,3470 C3522-3 B,0.5D,1855 C3522-4 B,0.75D,320 SJ542 B,2.5D,1535 C0510-27C0436-27 C1536-1 B,4.0D,1740 Switchpack-Seats-Rear-Left C0435-19C0510-19 B,0.5D,1855 C3522-1 C0510-11C0436-11 R,0.5D,2040 C3538-12 C3539-12 R,0.5D,180 SJ742 R,0.5D,170 RG.0.5D.4120 C3522-3 B,0.5D,1855 Sheet2 C3522-4 B,0.75D,320 SJ542 B,2.5D,1535 C0510-27C0435-27 B,4.0D,1680 C2599-1 →[© C0585-31 R,2.5D,4095 C0583-21 FUSE 42P C0255-1_C0752-1 R,2.5D,160 Sheet2 0>>0 30.0 Amps FUSE 46P C0585-22 YR,2.5D,4095 C0255-2 C0752-2 YR,2.5D,160 Sheet2 0 30.0 Amps FUSE 45P C0585-24 RN,2.5D,5755 C0253-1 C0751-1 R,2.5D,160 0>0 30.0 Amps

C0253-2_C0751-2

YR,2.5D,160

